



PLAN

NOTES:

1. INSTALL REPAIR SLEEVE IN STRICT ACCORDANCE WITH MANUFACTURER'S INSTRUCTIONS.
2. THOROUGHLY CLEAN AND VIDEO INSPECT SEWER MAIN PRIOR TO INSTALLATION OF REPAIR SLEEVE.
3. UPON INSTALLATION OF REPAIR SLEEVE, THE CONTRACTOR SHALL VIDEO ENTIRE SEWER RUN FROM MANHOLE TO MANHOLE TO DOCUMENT INSTALLATION OF REPAIR SLEEVE.
4. ALL VIDEO INSPECTION TAPES SHALL BE FORWARDED TO OWNER UPON COMPLETION OF WORK.

HORSHAM WATER & SEWER AUTHORITY	DETAIL S20	SANITARY LATERAL ABANDONMENT DETAIL
DATE: SEPTEMBER 14, 2015		SCALE: NOT TO SCALE